

CIRCUITO STAMPATO SELETTORE AUDIO / VIDEO

SJE0S001A-U2

*1: 2SC2712(YG)-X
 *2: 2SA1162(YG)-X
 *3: MA3130(H)-X
 *4: MA141WK-X
 BW: BUS WIRE
 0: 0Ω RESISTOR
 X: NON MOUNT (OPEN)



