



SONY XR-3750




SONY XR-3750

【KEY BOARD】




• IC Block Diagrams
– MAIN Section –


IC301 CXA2509AQ-T4



IC331 LC75373ED




IC611 BA3918-V2



• Waveform
– MAIN Section –

① IC501 (X-IN)



IC351 MM1322XFB

